

# DOMINION OFFROAD

## HI-LIFT ACCESSORY BARS

Phone: 626-Trails1 or 626-872-4571

### INSTALLATION

#### Kit Contents:

(2) Accessory Bar Brackets	(4) Plastic QF Washers	(4) Quick Fists
(4) Flat Head Machine Screws	(4) Wing Nut Washers	(4) 3/16" Nuts

1. Use Thread Locker on Quick Fist Fasteners.
2. Tighten all other fasteners with a wrench or pliers.

*Write-ups and posts, on the forums are greatly appreciated.  
Spread the word and thank you!*

# DOMINION OFFROAD

## HI-LIFT ACCESSORY BARS

Phone: 626-Trails1 or 626-872-4571

### INSTALLATION

#### Kit Contents:

(2) Accessory Bar Brackets	(4) Plastic QF Washers	(4) Quick Fists
(4) Flat Head Machine Screws	(4) Wing Nut Washers	(4) 3/16" Nuts

1. Use Thread Locker on Quick Fist Fasteners
2. Tighten all other fasteners with a wrench or pliers.

*Write-ups and posts, on the forums are greatly appreciated.  
Spread the word and thank you!*



[www.DominionOffRoad.com](http://www.DominionOffRoad.com)



[www.DominionOffRoad.com](http://www.DominionOffRoad.com)