

DOMINION OFFROAD

Jeep JK Hard Top Saver Kit - Installation Instructions (626) Trails1 or (626) 875-4571

Your new Hard Top Saver Kit is manufactured of 304 Stainless Steel. Painting for reasons of providing rust protection is not required.

Kit Contents: (6) Double Sided Tape backed Stainless Steel Plates

Required Tools: - T-40 Torx Wrench - Two Hands (though you could probably get away with one)

Warning: VHB Tape is not very forgiving. Align the plates carefully and get it right the first time.

Installation Procedure:

1. Other than the top two fasteners (located under the freedom top panels) remove all of the Hard Top fasteners
2. Remove double sided tape backing from Hard Top Saver Plate
3. Align the hole of the Saver Plate with the Hard Top Fastener hole and press in place



Write-ups and comments on Jeep Forums,
are greatly appreciated.

Thanks,

Brett
(626) Trails1
brett@JeepSWAG.com

