

# DOMINION OFFROAD

Phone: 626-Trails1 or 626-872-4571

## Jeep JK

### 4 AT ONCE TIRE FILLING HOSE ASSEMBLY



Until the Dominion OffRoad Hose Kit is available, we are providing these instructions that will allow you to make your own Hose Kit.

Parts required: (One 25' Hose will make assemblies for both sides)

(4) Screw-On Tire Chucks (Include with OBA Kit)

(1) 25' Air Hose: Harbor Freight Item # 93336

(2) .25" Brass Barb Tee Fittings:

<http://www.veneersupplies.com/products/Brass-Barbed-Tee.html>

(10) Small hose clamps (pinch clamps work best)

(4) 6mm barbed closed type tire chucks:

[http://veesun.com/european\\_style\\_air\\_tire\\_chuck](http://veesun.com/european_style_air_tire_chuck)

Optional Heat Shrink Tubing

1. Cut the hose in two even halves.
2. From the Pipe Thread fitting, cut each hose at 18".
3. Cut each of the remaining hoses at 58" (the remaining hose length should be 73").
4. Assemble according the picture on page 1.
5. Heat shrink tubing over the hose clamps are good.

Link to Air Fill Tips and Tricks Video: <http://www.youtube.com/watch?v=wpKX6yC3nVw>

Visit [www.DominionOffRoad.com](http://www.DominionOffRoad.com)

